

3. Put the object(s) on the center of weighing platform.
4. Press "MODE" key to switch between the units.

## II. Tare Function

1. Turn on the scale as described above.
2. Place the "tare item" on the platform.
3. Press "TARE" key and wait until the LCD displays "0.0" or "0.00".
4. Add the "net-weight-item".

## III. Calibration

1. When the scale is turned off, press ON/OFF key to turn on the scale, wait until "0.0" or "0.00" is displayed.
2. Press and hold the "MODE" key until the display shows "CAL.", then release the button. Press "MODE" key again and then the required weight flashes on the display. Place the required weight onto the center of the platform.
3. The LCD display reads "PASS" and come back to the normal weighing mode. Calibration is complete.

Repeat this process if something was going wrong.  
Please check the availability of weights at the store you bought your scale from.



26.05<sup>g</sup>

Capacity: 200g

Graduation: 0.01g

TARE

MODE

ON  
OFF